

Модульное тепловое оборудование **thermaline Modular 90**

Подставки открытые, сквозные, закрытые **Electrolux Professional** Технические характеристики

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Казахстан (772)734-952-31

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Closed Bases - H 450



	■ 589599	■ 589601	■ 589631
External dim. - mm			
Width	100	200	300
Depth	900	900	900
Height	450	450	450

Open Bases - H 450



	■ 589174	■ 589179	■ 589180	■ 589496	■ 589181
External dim. - mm					
Width	400	500	600	700	800
Depth	900	900	900	900	900
Height	450	450	450	450	450
Operating side	1-side	1-side	1-side	1-side	1-side

Open Bases - H 450



	■ 589175	■ 589176	■ 589177	■ 589178
External dim. - mm				
Width	900	1000	1200	1500
Depth	900	900	900	900
Height	450	450	450	450
Operating side	1-side	1-side	1-side	1-side

Cupboard Bases - H 450



	■ 589182	■ 589183	■ 589184	■ 589186	■ 589185
External dim. - mm					
Width	400	500	600	800	1000
Depth	900	900	900	900	900
Height	450	450	450	450	450
Operating side	1-side	1-side	1-side	1-side	1-side
Doors	1	1	1	2	2

Passthrough Open Bases 500 - 800mm - H 450



	■ 589193	■ 589194	■ 589188	■ 589195
External dim. - mm				
Width	500	600	700	800
Depth	900	900	900	900
Height	450	450	450	450
Operating side	2-side	2-side	2-side	2-side

Passthrough Open Bases 900 - 1500mm - H 450



	■ 589189	■ 589190	■ 589191	■ 589192
External dim. - mm				
Width	900	1000	1200	1500
Depth	900	900	900	900
Height	450	450	450	450
Operating side	2-side	2-side	2-side	2-side

Passthrough Cupboard Bases - H 450



	■ 589196	■ 589197	■ 589201	■ 589199	■ 589200
External dim. - mm					
Width	500	600	800	1000	1200
Depth	900	900	900	900	900
Height	450	450	450	450	450
Operating side	2-side	2-side	2-side	2-side	2-side
Doors	2	2	4	4	4

Closed Bases - H 550



	■ 589600	■ 589602	■ 589632
External dim. - mm			
Width	100	200	300
Depth	900	900	900
Height	550	550	550

Open Bases - H 550



	■ 589310	■ 589315	■ 589316	■ 589497	■ 589317
External dim. - mm					
Width	400	500	600	700	800
Depth	900	900	900	900	900
Height	550	550	550	550	550
Operating side	1-side	1-side	1-side	1-side	1-side

Open Bases - H 550



	■ 589311	■ 589312	■ 589313	■ 589314
External dim. - mm				
Width	900	1000	1200	1500
Depth	900	900	900	900
Height	550	550	550	550
Operating side	1-side	1-side	1-side	1-side

Cupboard Bases - H 550



	■ 589318	■ 589319	■ 589320	■ 589322	■ 589321
External dim. - mm					
Width	400	500	600	800	1000
Depth	900	900	900	900	900
Height	550	550	550	550	550
Operating side	1-side	1-side	1-side	1-side	1-side
Doors	1	1	1	2	2

Passthrough Open Bases - H 550



	■ 589329	■ 589330	■ 589324	■ 589331
External dim. - mm				
Width	500	600	700	800
Depth	900	900	900	900
Height	550	550	550	550
Operating side	2-side	2-side	2-side	2-side

Passthrough Open Bases - H 550



	■ 589325	■ 589326	■ 589327	■ 589328
External dim. - mm				
Width	900	1000	1200	1500
Depth	900	900	900	900
Height	550	550	550	550
Operating side	2-side	2-side	2-side	2-side

Passthrough Cupboard Bases - H 550



	■ 589332	■ 589333	■ 589337	■ 589335	■ 589336
External dim. - mm					
Width	500	600	800	1000	1200
Depth	900	900	900	900	900
Height	550	550	550	550	550
Operating side	2-side	2-side	2-side	2-side	2-side
Doors	2	2	4	4	4

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Казахстан (772)734-952-31

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93